



SAFE CAMS Y2

USER MANUAL



www.safecams.in

Thank you, for purchasing a SAFE CAMS dash camera.

Disclaimer

1. Please read the set up and usage instructions carefully before operation.
2. You should not install this dash camera at a place that would obstruct or reduce the driver's view. Make sure your usage of the device complies with pertinent vehicle codes/laws in your state in India.
3. You should post the required notices of recordation to occupants inside the vehicle, if voices or other information pertaining to in-vehicle activities will be recorded.
4. You should not change the dash camera's settings or mode of operation while the vehicle is moving.
5. You should not leave the dash camera in a visible spot when there is no one inside the vehicle, to avoid attracting break-ins to steal the unit or other property.
6. You should avoid extended exposure of the dash camera to direct sunlight or extreme

temperatures (either high or low temperature) which tends to degrade or damage the unit and its normal functionality.

7. You should examine, check and verify the dash camera, including the memory card, at least every 3 months to ensure that the video reception and recording are working properly. Verify that the dash camera, visible lights and audible sounds are working properly. Ensure that the memory card is formatted every 6 weeks to ensure it works properly. If there are signs of non-operation or malfunction, you should immediately seek to replace the product and check to see if the product is covered under any applicable warranty.

8. The dash camera unit may have additional functionality, such as transmission and recordation of audible or GPS signal or other identification information. If you have any privacy concerns about these functions, make sure to follow the instructions to disable these functions.

9. You should use the dash camera unit in the way it is intended. You should not use the dash camera in a way that is illegal, or that tends to physically damage the unit, or will cause danger to the safe operation of the vehicle and its occupants.

10.This device should not be adjusted by the driver while driving as the device may become dislodged in the event of an accident and could become a danger to the passengers.

Note

1.This user manual will detail how to use the dash camera. It's operational and technical specifications and precautions. Before use please read this manual thoroughly and fully understand it. Please keep this manual safe. We hope our product will meet your needs and give you long-term service.

2.The dash camera is not waterproof, please do not keep it in damp or wet conditions as it will impair its operation. Ensure that it is not exposed to rainwater.

3.Do not try to open the shell of the device or try and repair the device or its accessories by yourself. Please contact SAFE CAMS so that a professional person can repair the device.

4.Do not use any chemical substance or cleaner solvent to clean the device. Please use a moist soft cloth to clean.

5. Please do not use this device in extremely dusty conditions, as it will affect the video quality.

6. Please protect the environment, don't discard this machine randomly or throw it into a fire. Recycle it if your state has an electronics waste management system.

7. Please ensure that the lens is kept clean with a moist soft cloth to ensure you get the best video footage from your dash camera.

Tips

1. Please avoid high temperatures and direct sun exposure.

2. Please use original accessories.

3. Do not disassemble the product.

Product Structure



Product Installation Guide

1. Turn off the vehicle engine.

2. Insert the SD card into the card slot.

ATTENTION Please use a high-speed SD card (Class 10 or above), capacity is not less than 8GB. Max Capacity will be based on the model you have purchased, please check the specifications section of the manual. Please format the card with the dash camera from the settings section.

3. Fix the dash camera on to the windscreen of your vehicle.


4. Connect the hardwire kit to the correct power supply via the fuse tap.

Yellow Wire – B+ to the positive battery power supply (constant power)

Red Wire – ACC (power supply when the ignition is turned on)

Black Wire – GND to ground terminal in the vehicle. This could be a bolt/screw that is attached to the vehicles metal body.

AV cable – that is the video AV output from the device so it can be connected to an AV input device to show the camera's video footage.



5.Ensure that the power cable is neatly tucked into the roof of the car, along the rubber tubing along the side of the door and under the lower part of the dashboard to the fuse box. This will ensure that there are no loose wires in the vehicle from the dash camera to the power supply.

6.Pay attention to the direction of the wiring when installing the rear camera. The wiring can be concealed in the roof or rubber tubing of the vehicle. Affix the rear camera to the rear windscreen or just beneath the boot lid depending on your vehicle type. The rear camera is connected via the AV-IN cable to the main unit. There is no need to connect the red reversing wire on a no screen dash camera.

7.Adjust the lens position to ensure that the camera covers the entire view from the rear and front of the vehicle. Also ensure that the camera is not recording too much of the vehicle's bonnet.

8.Once all the wires are connected, switch the vehicle on, the dash camera will start automatically, with a red/blue light blinking on the device.

Installation Precautions

1.Before installation, please check that you have all accessories and that they are correct and complete.

2.During installation please do not turn your vehicle on until you are sure all the wires have been connected as directed. Also do not pull out any dash camera accessories while the device is in the Power ON status. This includes rear camera, SIM card, SD card and GPS antenna.

3.When the vehicle is turned on, the dash camera will automatically turn on. Please check whether the function of the power on/off, the front and rear camera displays are working. (You will have to check this via the mobile app if the camera does not have a screen)

4.When the device is in use and the power is on, it is forbidden and dangerous to pull or insert the

rear camera plug, GPS antenna or SD card. This action can cause serious harm to the device and cause the video files to become corrupt.

5.To view the video footage from the physical SD card (if the device has WIFI, then you can connect to it via WIFI to access the video footage), turn the device off, and then only remove the SD card. You can then insert the SD card into your computer so that you can view the recorded footage.

6.You must use a Class 10 or higher speed SD card with the right memory capacity. Lower than Class 10 will cause problems like video stutter, black screen or your video footage not being recorded at all.

7.Please use the mobile application recommend by SAFE CAMS to connect to our dash camera via WIFI.

Product Specifications

- Chipset: Novatek
- Sensor: Sony Low Light Sensor
- Lens: 170° ultra-wide-angle lens
- Video Resolution: Full HD 1080p @ 30fps
- Photo Resolution: 12MP
- WIFI: supported via Android and Apple apps
- Loop recording
- Video encoding: H.264
- G-Sensor
- Built in Microphone
- Parking Guard support with Hardwire Kit
- Wide Dynamic Range for great night footage
- Super capacitor
- Max SD card 64GB
- Operating Temperature: -20°C ~ +60°C
- Storage Temperature: -30°C ~ +70°C
- Accessories: Hardwire Kit, 3M Adhesive

WIFI APP

1. Please download the application for Android or Apple using the QR codes below:



ANDROID



IOS

2. Turn on your dash camera, you will see blue and red light flashing on the power side of the device.


3. Open the mobile application.

4. You will be redirected to WIFI section of your phone.

5. Look for Dash camera WIFI name, enter password and connect. WIFI name will be FirstsceneY2-XXXX. The password is 12345678.

6. After successful connection you can see dash camera view through the mobile app.

7. On first connection, please go to settings and format the SD card.



info@safecams.in

www.safecams.in

+91 84477 46202